

SIMPLE DAY

living & lifestyle

BORRACCIA TERMICA - Istruzioni per l'uso e manutenzione

La borraccia termica è realizzata in acciaio inossidabile a doppia parete. Questa tecnica permette al prodotto di mantenere la temperatura dei liquidi caldi fino a 8 ore o freddi fino a 12 ore.

Prima dell'utilizzo lavare accuratamente il prodotto e consigliamo di lavarlo dopo ogni utilizzo, soprattutto se impiegato per conservare un liquido diverso dall'acqua. Suggeriamo anche di effettuare dei lavaggi regolari, una buona manutenzione permette di usare per molti anni il tuo prodotto.

È possibile utilizzare semplicemente acqua calda e sapone neutro, oppure una miscela di acqua calda e aceto oppure un cucchiaino di bicarbonato di sodio, in alternativa si può utilizzare normale sapone per piatti. Una volta lavati, lascia sempre asciugare i prodotti rovesciati e senza il tappo. Piccole macchie possono apparire all'interno della bottiglia a causa dell'uso continuo, in particolare con caffè o tè nero, ma non cambierà la sicurezza e la durata del prodotto. Non usare detergenti o spugne abrasive.

Lavare a mano. Il prodotto non deve venire lavato in lavastoviglie. I liquidi non dovrebbero rimanere per più di 24 ore all'interno della borraccia, dopo il lavaggio consigliamo di lasciare asciugare completamente l'interno prima di chiudere la borraccia.

Non utilizzare in forno microonde, forno tradizionale, fornello o altro. Non utilizzare in congelatore. Non utilizzare per bevande acide.

Fare attenzione alla temperatura dei liquidi caldi prima di bere. Non riempire completamente la borraccia e controllare che sia chiusa completamente e correttamente prima di riporla.

THERMAL BOTTLE - User and Maintenance Instructions

The thermal bottle is made of double-walled stainless steel. This technique allows the product to maintain the temperature of hot liquids for up to 8 hours or cold liquids for up to 12 hours.

Before use, wash the product thoroughly and we recommend washing it after each use, especially if it is used to store a liquid other than water. We also suggest regular washes; good maintenance allows you to use your product for many years.

You can simply use hot water and mild soap, or a mixture of hot water and vinegar teaspoon of baking soda; alternatively, you can use regular dish soap. Once washed, always let the products dry upside down and without the cap. Small stains may appear inside the bottle due to continuous use, particularly with coffee or black tea, but this will not affect the safety and durability of the product. Do not use abrasive cleaners or sponges.

Hand wash only. The product should not be washed in the dishwasher. Liquids should not remain inside the bottle for more than 24 hours; after washing, we recommend letting the interior dry completely before closing the bottle.

Do not use in microwave oven, traditional oven, stovetop, or other. Do not use in the freezer. Do not use for acidic beverages.

Be careful with the temperature of hot liquids before drinking. Do not completely fill the bottle and ensure that it is completely and correctly closed before storing it.

